


What should I do when the machine shows an alarm screen and stops working?



When a machine alarm occurs, an alert screen will appear on the display. This indicates that the machine cannot continue operating until the issue is resolved. Press the “?” for this specific alarm type for instructions on how to resolve.